



Control Unit Wire Adjustment

【Model: SKRW-IS, SPRW-IS】

When attaching the control unit to the bottom of the table top, follow the steps below.



Adjust the control wire position.



Install the 2 screws.

Control Unit



Slide the control lever all the way to Ignition position



Slide the control lever all the way to Stop position

Slide the lever 2x as shown on the left and compare where the lever rests. Reference the diagram to the right.



The lever has to be centered in this position



If not centered correctly, there may be issues while trying to ignite the flame

Adjust lever position



Use a flat screw driver to open the cover.



Correctly adjust the lever's position by turning the gold knob. Reference the diagram above for correct positioning. Close the cover after checking.